

# Silicon Carbide (SiC) Temperature Measurements in NSUF Experiments

Troy Unruh  
April 16<sup>th</sup>, 2024

Battelle Energy Alliance manages INL for the  
U.S. Department of Energy's Office of Nuclear Energy



Idaho National Laboratory

# Introduction

- Provide a practical and robust approach to estimate peak irradiation temperature during PIE for direct integration in irradiation test designs:
  - Less expensive static (drop-in) capsule tests with no leads will essentially be the only possibility for peak temperature indication
  - Determine a peak temperature reached within a relatively broad range (200 – 1200°C) resulting in accuracies within  $\pm 20^\circ\text{C}$
  - Neutron irradiation induced lattice expansion of SiC annealed out when the post-irradiation annealing temperature exceeds the peak irradiation temperature
  - Property change (lattice spacing, **dimensions, electrical resistivity**, thermal diffusivity, or bulk density)
- Joined collaboration between NSUF and Advanced Sensors and Instrumentation (ASI) Program



# SiC Material

- SiC rod (1 mm OD by 12.5 mm) and disks (OD 3 mm or 5 mm by 1 mm)
  - Procured from PremaTech Advanced Ceramics
  - Follow Rohm and Haas specification sheet:
    - chemical vapor deposition (CVD) SiC
    - high resistivity grade ( $>1000 \Omega \text{ cm}$ )
    - highly pure (99.9995%) with theoretical density and with no voids or micro cracks
    - face-centered cubic  $\beta$  crystal structure (isotropic characteristics)
    - performance at high temperatures (up to  $1700^\circ\text{C}$ )
    - resistance to corrosion, oxidation, erosion, wear, and abrasion
    - hardness (second only to diamond) with high strength



# Resistivity Method

- Environment Temperatures in Air: 200 – 800°C
- Recommended dose ranging from 0.5 – 8 dpa
- Electrical resistivity is accepted as a robust measurement technique resulting in accuracies within 20°C
- Very time and labor intensive (1 week to 3 week per sample)
- Can only process SiC sticks






Spring loaded resistance measurement fixture. The SiC monitor is held in place between the two copper electrodes.



# Optical Dilatometry

- Thermal expansion from continuous dilatometry is an automated process requiring minimal setup time (simple process)
- Dilatometer runs under vacuum (no oxidation issues as can happen with Resistance Method)
- Temperatures: 200 – 1200°C (accuracies +/-20°C )
- Recommended dose ranging from 0.5 – 8 dpa
- Time to process each sample 2 to 3 days (Resistance Method can be 1 to 3 weeks)
- Rods, square shaped pillars and disks may be used (Resistance Method cannot process disks)




# Dilatometer Advantages

- Contactless dilatometric measurement system (no error due to sample placement with push-rod dilatometer)
  - freely expand/shrink without any interference from mechanical contact
  - more precise determination of the passive monitor's dimensional changes and the temperature at which the changes are detected
- Effective environmental control during the testing
  - vacuum or in an inert atmosphere—a key requirement for avoiding any oxidization issues, which prolongs the resistivity method

# NSUF ISU N-SERT Experiment

- Awarded under NSUF number ISU-10537
- Collaborated with ISU - Dr. Haiming Wen as the principal investigator
- Objective: Irradiation performance of ultrafine-grained and nanocrystalline variations of reactor structural and cladding steels produced using severe plastic deformation manufacturing techniques

Capsule Number	Design Temperature [°C]	Exposure [dpa]	Capsule Position in ATR
1	300 +/- 50	2 +/- 10%	Top
2	300 +/- 50	6 +/- 10%	Middle Top
3	500 +/- 50	6 +/- 10%	Middle Bottom
4	500 +/- 50	2 +/- 10%	Bottom




# SiC temperature Monitors

- Total of 8 SiC TMs
  - Each capsule had two SiC TMs (placed between TEM specimens)
  - Provided thermal model estimates for each SiC location in the capsule

SiC Number	MSL Identification	HFEF Identification	Temperature Estimates for SiC [°C]		
			T min	T max	Avg
1	HTTL-244L2-R1	KGT 3828-1	336	337	336.5
2	HTTL-243U1	KGT 3828-2	333	335	334
3	HTTL-242L1-R1	KGT 4600	345	347	346
4	HTTL-244-U2	KGT 4609	341	343	342
5	HTTL-243L1-R1	KGT 4639-C	506	507	506.5
6	HTTL-243L2	KGT 4639-D	499	501	500
7	HTTL-241L2	KGT-3841-3	517	519	518
8	HTTL-242U2	KGT-3841-4	509	511	510



# SiC TMs annealed in Optical Dilatometer



- Thermal expansion from continuous dilatometry used to calculate the SiC irradiation temperature
- Annealing Max. Temp: 800 C
- Design/Target Temp: 300°C
- Irradiation temperature measured using the difference of the SiC length change between heating and cooling
- Peak irradiation temp. was 200°C +/- 20°C
- The steady-state irradiation temperature ranged between 190°C and 200°C

# SiC TM Results


- All 8 SiC were successfully processed in the optical dilatometer
  - All but 3 SiC TMs met the target/design temperature ranges
  - All thermal temperature predictions were overestimated

HFEF Identification	Design Temp. [°C]	Thermal Model Avg. Temp. [°C]	Avg. Peak Irradiation Temp. [°C]	Met Design Temp.	Met Thermal Model Avg. Temp.
KGT 3828-1	300+/-50	336.5	270+/-20	YES	Below
KGT 3828-2	300+/-50	334	230+/-20	YES	Below
KGT 4600	300+/-50	346	200+/-20	Below	Below
KGT 4609	300+/-50	342	300+/-20	YES	Below
KGT 4639-C	500+/-50	506.5	440+/-20	YES	Below
KGT 4639-D	500+/-50	500	280+/-20	Below	Below
KGT 3841-3	500+/-50	518	480+/-20	YES	Below
KGT 3841-4	500+/-50	510	410+/-20	Below	Below

# SiC swelling

- Increase in volume due to radiation-induced swelling
- Little change in the crystal volume is expected at annealing temperatures lower than the irradiation temperature
- Dramatic decrease in volume is expected when the annealing temperature surpasses the irradiation temperature
- Averaged 27.9  $\mu\text{m}$  neutron-induced swelling & 11.2  $\mu\text{m}$  post annealing shrinkage
  - Critical to include enough space in capsule design to avoid sensor getting stuck

SiC Number	Diameter [ $\mu\text{m}$ ]				
	Pre-Irradiation	Post-Irradiation	$\Delta\text{OD}$	Post-Annealing	$\Delta\text{OD}$
1	3000	3030.8	30.8	3020.3	-10.5
2	3000	3031.4	31.4	3018.3	-13.1
3	3000	3031.4	31.4	3017.3	-14.1
4	3000	3023.2	23.2	3009.9	-13.3
5	3000	3021.7	21.7	3016.1	-5.6
6	3000	3027.5	27.5	3017.6	-9.9
7	3000	3030.8	30.8	3013.4	-17.4
8	3000	3026.6	26.6	3020.8	-5.8
<b>Average</b>	<b>3000.0</b>	<b>3027.9</b>	<b>27.9</b>	<b>3016.7</b>	<b>-11.2</b>



## Limitations

- Temperatures are inferred by post-irradiation detection of changes in material properties:
  - If there is a power outage to the equipment during your annealing process – the results are lost (you can only anneal the point defects once)
  - Ideal sensor for steady-state power -> if more temp. fluctuations the more difficult to determine peak irradiation temp. and higher error
  - It will not detect irradiation temperatures that had lower than 0.1 dpa of neutron damage (i.e., spikes of power/temperature during irradiation)

# Conclusions

- Optical dilatometer can successfully process SiC sticks and disks
- No oxidation issues (inert or vacuum chamber)
- All but 3 SiC TMs met the design/target temperature ranges
- All thermal temperature predictions were overestimated

# Future Work

- Work with NSUF on creating a road map for using passive sensors in irradiation experiments
  - Attend “Best Engineering Practices” event at ORNL to start the process of creating an ASTM standard for using and processing SiC TMs
- 
- Technical details can be found in "Assessment of Readout Techniques for Passive Monitors" by M. Wilding, Summary Report, March 2024
  - E-mail: Malwina Wilding at [Malwina.wilding@inl.gov](mailto:Malwina.wilding@inl.gov) for details



# Idaho National Laboratory

*Battelle Energy Alliance manages INL for the U.S. Department of Energy's Office of Nuclear Energy. INL is the nation's center for nuclear energy research and development, and also performs research in each of DOE's strategic goal areas: energy, national security, science and the environment.*